

WINDOWART

How to Remove Blinds

For Vision(Zebra) blinds
& Honeycomb blinds



- **Locate the Brackets**

Check

Find the metal brackets at the top of the blind. The front part has a hook where the blind is held, and the back part has a spring clip.




Side view



- **Lift the Back of the Bracket**

Check

Using your finger or a flat tool, gently push up the back clip of the bracket. This will release the blind from the bracket.



- **Remove the Blind**

Check

**Carefully lower the blind away from the brackets.
Repeat for all brackets until the blind is fully removed.**

WINDOWART

THANK YOU!

Thank you for choosing us.



021 0243 0664



www.windowart.co.nz



103B Main South Road, Sockburn,
Christchurch